


## Spare parts for three points internal micrometer 3227-B series



Part NO.	Code	Description
1	SP-POLE-3227-1	100mm Extension rod for 3227-8/-10/-12
	SP-POLE-3227-E-1	4" Extension rod for 3227-E035/-E043/-E05
2	SP-WRENCH	Wrench
3	SP-SPANNER-3227-2	Hex wrench
4	SP-HEAD SCREW-3227-8	Screw for measuring head (3227-8)
	SP-HEAD SCREW-3227-10	Screw for measuring head (3227-10)
	SP-HEAD SCREW-3227-12	Screw for measuring head (3227-12)
5	SP-MEASURING HEAD-3227-8	Measuring Head (3227-8)
	SP-MEASURING HEAD-3227-10	Measuring Head (3227-10)
	SP-MEASURING HEAD-3227-12	Measuring Head (3227-12)
	SP-MEASURING HEAD-3227-E035	Measuring Head (3227-E035)
	SP-MEASURING HEAD-3227-E043	Measuring Head (3227-E043)
	SP-MEASURING HEAD-3227-E05	Measuring Head (3227-E05)
6	SP-SCREW-3227-1	Screw
7	SP-RACHET-2	Measuring force device
8	SP-UPPER PART-3227-8	Upper part for 3227-8