


Spare parts for universal magnetic stand 6208-80A/6208-80



Part NO.	Code	Description
1	SP-HOLDER-6208-80	Dial Holder for 6208-80
	SP-HOLDER-6208A	Dial Holder for 6208-80A
2	SP-STAND-KNOB-6208	Tightening knob
3	SP-MAGNETIC BASE-6208	Magnetic Base
4	SP-STAND-SPANNER-6208	Magnetic switch
5	SP-STAND-UPPER-6208-80	Upper part for 6208-80
	SP-STAND-UPPER-6208-80A	Upper part for 6208-80A
6	SP-SCREW-6208-80A	Screw for 6208-80A